

## お取扱い上の注意

- ⚠️ 直火、電子レンジでご使用になれません。
- ⚠️ ご使用中に、ガラス本体とホルダーの取付けにガタやゆるみなどの異常を感じた場合、危険ですので使用しないでください。
- ⚠️ お子様がご使用になる際は、取扱い上の注意をご指導の上、一人では扱わせないようにしてください。また、幼児のそばで使用したり、幼児の手の届く所に置かないでください。
- お使いになる際は、必ずホルダーの取っ手をお持ちください。
- お飲物を入れて凍らせないでください。
- ご使用前には洗淨してください。



熱湯用

⚠️ 注意

● 直火にかけられません



食洗機OK

HEATPROOF GLASS

For hot drink

Do not expose to Open flames

Dishwasher-safe

Heatproof temperature difference: 120°C

Holder: Stainless steel

# HCGN-350

## ホットカフェグラス

### Hot cafe glass

満水容量/Practical Capacity

# 365ml

HCGN-350SV



4 977642 221260

シールバー

## お手入れの方法/Product Care

- ⚠️ 洗淨する場合は、やわらかいスポンジに中性洗剤を使用してください。
- ⚠️ やわらかいスポンジでも、下図のようにクレンザーやガラスに傷のつく研磨材、または研磨粒子がついているスポンジなどは使用しないでください。思わぬときに破損する原因となります。
- 本製品は食器洗い乾燥機のご使用ができます。ご使用の際は、お手持ちの食器洗い乾燥機の取扱説明書をよくお読みください。
- ガラスの汚れのひどいときは「家庭用漂白剤」を薄めてご使用ください。その際「家庭用漂白剤」の取扱注意事項を必ずお守りください。漂白後は十分に水洗いしてください。

- ⚠️ Use a soft sponge and mild dish detergent for cleaning.
- ⚠️ Do not use brushes and abrasive components (either powder or liquid) to clean the glassware. It may cause the glass breakage.
- This product may be washed in a dishwasher. Please follow the instructions of dishwasher properly.
- Diluted household bleach may be used for cleaning tough stains of glass. When using household bleach always follow the instructions

