



取扱説明書

お買いあげ誠にありがとうございます。正しくご使用していただくため、この取扱説明書を 必ずお読みください。また、お読みになりましたら、大切に保管してください。

Instruction Manual

Thank you for purchasing this HARIO product. Please be sure to read this instruction manual thoroughly prior to use.

After reading the manual, store it in a safe place for future reference.

製品についてのお問い合わせ先


HARIO株式会社

〒103-0006東京都中央区日本橋 ナビダイヤル:0570-022-555 https://www.hario.com

HARIO CO., LTD.

9-3 Nihonbashi Tomizawa-Cho, Chuo-ku,Tokyo 103-0006 Japan

https://global.hario.com



Guideline for coffee grind adjustment

- 1. The "0" click is the point where the grind adjustment knob is aligned with the upper and lower "●".
- 2. Turn the adjustment knob clockwise and count "1 click, 2 clicks" each time you hear a "click" sound.

Granule size	Superfine	Fine	Medium-Fine Medium		Coarse
		Granulated sugar size	Between granulated and crystallized sugar		Crystallized sugar size
Clicks	12~25	25~35	35~45	45~60	60~90

%The above values are for reference only, so please adjust to your preference. Clicks will go above 90, but please only use up to 90 clicks.

Choosing the correct coarseness

Coarseness	Superfine	Fine	Medium-Fine	Medium	Coarse
Granule size (approx.) Brewing equipment		Granulated sugar size	Between granulated and crystallized sugar	Between granulated and crystallized sugar	Crystallized sugar size
Paper filter		•	•	•	
Paperless filter				•	•
Cloth filter			•	•	
Syphon			•	•	
Water dripper		•	•		
Coffee maker			•	•	
French press				•	•
Espresso	•				

The recommended coarseness may differ depending on the type of equipment used. See the instruction manual of your coffee-making equipment for more details. Always use fresh coffee beans.

Precautions for Use

- ♠ Do not touch the burr directly with your hands as it is sharp. Wear gloves when cleaning the product to avoid injury.
- Always turn the handle clockwise. Never turn the handle in reverse or turn it empty, as this will damage the grinder.
- ↑ This product cannot be washed in water.
- •Do not grind forcibly with heavy rotation as it will damage the parts.
- ●Small, broken coffee beans, etc., may get into the bumps and crevices in the hopper, causing the coffee beans to not fall smoothly and the handle to spin around. Please tap the hopper lightly from time to time while grinding coffee beans. ●After prolonged use, the burr may become worn and lose its sharpness. The standard time to replace the product is when the amount of coffee beans to be ground becomes significantly less.●Do not use for anything other than coffee beans, as it may cause damage. ●Do not put your fingers in the burr gap when turning the handle, as it is dangerous. ●Please be careful not to hit the burr against a hard object or drop the main
- ●Do not strike or scrape the hopper or coffee ground bottle with hard or sharp objects. Doing so may cause scratches. ●When discarding, please separate according to the instructions provided by each local government.

unit, as this may cause damage to the burr.

Features


- Equipped with a burr made of high-hardness stainless steel that makes it easy to obtain uniform coffee grinds.
- •The bearing prevents wobbling of the shaft shake and stabilizesmakes for stable grinding.
- Click-type coffee grind size adjustment mechanism.
- High-precision integrated automatic precision processing.
- The shape makes it easy to hold and grind.

that prevents the inner and outer burrs

from completely colliding.

How to use

- 1.One cup of coffee (120 ml) should have about 10 to 12 g of coffee beans. Place 1 to 2 cups worth of coffee beans into the hopper and attach the lid handle and coffee ground bottle.
- 2.Coffee grind size setting. (See Guideline for coffee grind adjustment)
- Grind coffee beans by holding the main unit firmly with your hand and turning the handle slowly in a clockwise direction.
- *Never turn the handle counterclockwise, as this will damage the grinder.



HARIO

Product care

The burr can be disassembled for cleaning. Be careful not to lose any parts when disassembling.

[How to disassemble the burr]

- Remove the bottom container, unscrew the burr with the the driver provided and remove the burr. The handle is kept attached during this process. (Be careful not to lose the screws.)
- ②Remove the inner burr and burr holder. Be sure to wear gloves while removing the unit.
- (3) Use a soft bristle brush or similar tool to remove coffee grounds from both sides of the mortarburr. Do not touch the mortarburr directly with your hand because it is sharp. Do not wash it with water or wipe it with a damp cloth, as this may cause the mortarburr to rust. Also, do not wash the main body with water.

